

#### **INSTRUCTIONS:**

### Detail 'A'

- 1. Open the doors and place the shelf panel (P3)(P4) to the cabinet (P1). Open the brass shelf holder to adjust the hight level of shelf refer *detail 'A'*.
- 2. Put the marble top (P2) to the cabinet (P1) refer detail 'B'
- 3. Item is ready to use.
- (Adjust glider for the table leveling if necessary refer detail 'C').



# 6105-329

## LOCATION OF ANTI-TIP-KIT ASSEMBLY INSTRUCTION

Position for install bracket

**Pg**: 2/2 Ver: 01

#### ANTI TIP KIT INSTALLATION INSTRUCTION

- Attach brackets to the top back frame of the furniture and secure with short-screws.
- Determine the final position of the furniture piece and mark locations on the wall approximately 2" below the brackets mounted at the back of the furniture.
- Drill a hole into the wall stud. If wall stud is not available, drill a hole into the solid wall and insert plastic anchor and gently tap the anchor until the flange is flush in the wall surface.
- 4. Attach the second set of brackets by inserting the long-screws through the bracket holes and into the wall.
- Align the brackets at the back of furniture with the brackets in the wall.

Attach the Galvanized Steel Cable to the bracket and secure with clevis pin and hitch pin.





