



Loxely (Bronze)
10500B



Corner Chair
10505-40

W 40	D 40	H 36	SH 19	AH 28	ISW 34	ISD 24 (in)
W 102	D 102	H 91	SH 48	AH 71	ISW 86	ISD 61 (cm)


(2) 18*18 Throw Pillow



Left / Right Arm Facing Chair
10503-40 / 10504-40

W 40	D 40	H 36	SH 19	AH 28	ISW 34	ISD 24 (in)
W 102	D 102	H 91	SH 48	AH 71	ISW 86	ISD 61 (cm)


(2) 18*18 Throw Pillow



Left / Right Arm Facing Loveseat
10513-80 / 10514-80

W 80	D 40	H 36	SH 19	AH 28	ISW 73	ISD 24 (in)
W 203	D 102	H 91	SH 48	AH 71	ISW 185	ISD 61 (cm)


(4) 18*18 Throw Pillow



Left Arm Facing Right Corner Sofa / Right Arm Facing Left Corner Sofa
10525-120 / 10526-120

W 120	D 40	H 36	SH 19	AH 28	ISW 114	ISD 24 (in)
W 305	D 102	H 91	SH 48	AH 71	ISW 290	ISD 61 (cm)


(7) 18*18 Throw Pillow



Left Arm Facing Right Corner Loveseat
Right Arm Facing Left Corner Loveseat
10515-80 / 10516-80

W 80	D 40	H 36	SH 19	AH 28	ISW 74	ISD 24 (in)
W 203	D 102	H 91	SH 48	AH 71	ISW 188	ISD 61 (cm)


(5) 18*18 Throw Pillow



Left / Right Arm Facing Sofa
10523-120 / 10524-120

W 120	D 40	H 36	SH 19	AH 28	ISW 113	ISD 24 (in)
W 305	D 102	H 91	SH 48	AH 71	ISW 287	ISD 61 (cm)

(6) 18*18 Throw Pillow



Left / Right Arm Facing Chaise
10533-40 / 10534-40

W 40	D 80	H 36	SH 19	AH 28	ISW 33	ISD 64 (in)
W 102	D 203	H 91	SH 48	AH 71	ISW 84	ISD 163 (cm)

(2) 18*18 Throw Pillow